

EZ LATCH ONTO WOOD

EZ LATCH INSTALLATION ON TO WOOD

The EZ Latch works with almost any gate including wood, vinyl, or pipe. The following instructions are for EZ Latch installation on a wooden post. Installation is similar with a few notable differences.

REQUIRED MATERIALS

1. 10 mm keyless chuck drill OR 8 mm allen key (read below)
2. Drill bit (size depending on method used)
3. Marking pen
4. Crescent wrench
5. EZ Latch Kit for wood post using lag screws

1 INSTALLATION PROCEDURE

1. Position the latch pin on the gate at the desired height.
2. Drill a clearance hole for the $\frac{3}{8}$ " latch pin in gate down tube.
3. Position the EZ Latch to make contact with the pin on the rest plate.
4. Make two dots with a marker at the center of the slots on the EZ Latch for bolts (See Figure below).
5. Drill holes for two 9,525 mm lag bolts (or a 8 mm hole if using lag screws when screwing directly to the post). Stainless steel lag screws and washers are provided. Due to the various sizes of posts, the through-bolts are not included in the kit and are an optional mounting method.

