

POST CENTERS


BUCKLEY FENCE POST CENTERS

Post center to post center measurements are used to measure post hole placements in the field.


Use these measurements to mark with spray paint where to use the auger to dig post holes.

POST & RAIL DIMENSIONS

Rail Size



Post Size



BUCKLEY FENCE POST CENTERS

Section Number	Meters	Millimeters	Centers in Exact Total mm
1	2.74	196.85	2,936.85
2	5.79	88.90	5,878.9
3	8.53	285.75	8,805.75
4	11.58	177.80	11,757.8
5	14.63	69.85	14,700.85
6	17.37	266.70	17,636.7
7	20.42	158.75	20,618.75
8	23.47	50.80	23,520.8
9	26.21	247.65	26,457.65
10	29.26	139.70	29,439.7
11	32.31	31.75	32,342.75
12	35.05	228.60	35,278.6
13	38.1	120.65	38,220.65
14	41.15	12.70	41,262.7
15	43.89	209.55	44,199.55
16	46.94	101.60	47,041.6
17	49.68	298.45	49,978.45
18	52.73	190.50	52,920.5
19	55.78	82.55	55,862.55
20	58.52	279.40	58,800.4
21	61.57	171.45	61,741.45
22	64.62	63.50	64,725.5
23	67.36	260.35	67,595.35
24	70.41	152.40	70,612.4
25	73.46	44.45	73,404.45
26	76.2	241.30	76,441.3
27	79.25	133.35	79,383.35
28	82.3	25.40	82,325.4
29	85.04	222.25	85,262.25
30	88.09	114.30	88,204.3
31	91.14	6.35	91,146.35
32	93.88	203.20	94,083.2
33	96.93	95.25	96,925.25
34	99.67	292.10	100,262.1
35	102.72	184.15	102,904.15