


GATE DIMENSIONS

STAND-ALONE GATE DIMENSIONS


Stand-Alone 1.22 m Gate Dimensions with EZ Latch




The installation dimensions for all stand alone Buckley Fence Gates are the same for all three sizes of gate, EXCEPT for the End Post Face to End Post Face measurement and the Gate Post Face to End Post Face measurement. These differentiating measurements are marked in the following figures in blue.

- End Post Face to End Post Face dimensions are exact and must be within ± 3 mm.
- End Post Face to Gate Post Face is exactly 76,2 mm. Reference page 21 for setting the spacing between End Post Face to Gate Post Face.

Stand-Alone Section Gate (~2.55 m) Dimensions with EZ Latch



Stand-Alone 3.66 m Gate Dimensions with EZ Latch




DUAL GATE DIMENSIONS

Dimension for any combination of Buckley Fence gates if used as doubles. Refer to the Stand-Alone Gate Dimensions on page 15 for individual gate dimensions.

For Dual Gates, you will measure from End Post to End Post and from Gate Post to Gate Post.


Dual 1.22 m Gates Dimensions



Buckley Drop Anchors clamp on the lower corner of your gate. The Drop Rods drop into 305 mm Ground Tubes. Installation instructions for the Drop Anchor and ground tubes can be found on page 32.


**GROUND TUBE
305 mm**

Dual Section Gates Dimensions




- The nominal opening between gate faces for Dual Gates is 108 mm when an EZ Latch is used. When not using an EZ Latch, the gap between gate faces is 83 mm. In this case, 25 mm should be removed from the End Post Face to End Post Face Spacing.


Dual 3.66 m Gates Dimensions




1.22 m + Section Gate Dimensions



1.22 m + 3.66 m Gate Dimensions



Section + 3.66 m Gate Dimensions



***Gate Post Face to Gate Post Face Dimensions are reference only and rounded to the nearest 6.35 mm. End Post Face to End Post Face Dimensions are exact and must be within the nearest 3.175 mm.